

Excitation and Detection of Plasma Response to 3D Magnetic Fields

Daisuke Shiraki



January 20, 2012


-
- Introduction and Motivation
 - What do we mean by 3D magnetic fields, and why are they important?
 - The HBT-EP Device
 - Detection of natural plasma modes
 - Active driving of plasma with external fields, and detection of the plasma response
 - Summary

-
- Introduction and Motivation
 - What do we mean by 3D magnetic fields, and why are they important?
 - The HBT-EP Device
 - Detection of natural plasma modes
 - Active driving of plasma with external fields, and detection of the plasma response
 - Summary


Fusion-relevant plasmas are confined magnetically



- To achieve the conditions necessary for fusion, extremely hot plasmas ($\sim 10^8 K$) must be confined. This requires magnetic confinement
- A tokamak is a toroidal confinement geometry characterized by helical magnetic fields created by a combination of external coils and self-generated fields from plasma current
- The tokamak is an axisymmetric 2D configuration.



Tokamak (2D)





Stellarator (3D)

- Because of its early success, the tokamak is currently the most actively studied confinement concept.

At high beta, tokamak plasmas can spontaneously become 3D



- When the beta (plasma pressure normalized to magnetic pressure) exceeds a critical value, an external kink instability appears, and the plasma becomes 3D




- These perturbations grow exponentially, and often lead to a catastrophic loss of confinement, known as a disruption
- The kink mode can be feedback stabilized by applying an external field of appropriate structure, amplitude, and phase
- The external kink mode places the most stringent beta limit on tokamak plasmas, thus understanding kink mode physics is crucial to the success of a tokamak reactor!

3D fields can also prevent instabilities



- In many machines, an instability called the edge localized mode (ELM) causes periodic bursts of energy release resulting in excessive heat loads to components
- One possible method of ELM control is the application of 3D fields to keep the plasma away from the stability limits
- The physics of ELM control with magnetic perturbations is not fully understood!




Y.Liang et al., PPCF 2007

Motivation: 3D effects play a crucial role in expanding tokamak operating space



- Understanding of 3D effects allows extension of tokamak operating space and leads to higher performance plasmas




“Fusion research has increased key fusion plasma performance parameters by a factor of 10,000 over 50 years; research is now less than a factor of 10 away from producing the core of a fusion power plant.” –ITER Organization

- The physics of plasma interaction with 3D fields is an active area of theoretical and experimental research worldwide!

- Introduction and Motivation
 - What do we mean by 3D magnetic fields, and why are they important?
- The HBT-EP Device
 - Detection of natural plasma modes
 - Active driving of plasma response by applying external fields
- Summary


HBT-EP studies the physics and control of beta-limiting instabilities such as the external kink



Typical Parameters



Major Radius:	92cm	Electron Temperature:	100-150eV ($\sim 10^6$ K)
Toroidal Field:	0.33T	Densities:	10^{19}m^{-3}
Plasma Current:	10-15kA	Pulse Length:	10ms

HBT-EP is designed for detailed measurements of 3D effects





- The modular control coils and large number of magnetic sensors allows the high-resolution, high-accuracy excitation and detection of plasma response to 3D external fields



Magnetic sensor arrays give detailed picture of the 3D fields







Magnetic sensor arrays give detailed picture of the 3D fields





Magnetic sensor arrays give detailed picture of the 3D fields



Magnetic sensor arrays give detailed picture of the 3D fields




High-resolution measurements of natural fluctuations can be decomposed into independent plasma modes



- A Singular Value Decomposition of the data matrix decomposes the signal into a strongly ordered series of orthogonal plasma modes



$$A = U\Sigma V^\dagger = \sum \sigma_i \mathbf{u}_i \otimes \mathbf{v}_i$$

A rich spectrum of natural modes is observed from passive measurements of HBT-EP plasmas




- The dominant mode structure that we measure is a 3/1 helix, followed by a 6/2, and ?/3 helix at much lower amplitude. These are modes that resonate with the helicity of the equilibrium field
- These are independently evolving modes which must be simultaneously controlled in a feedback scheme!

Plasma can also be probed with an external magnetic perturbation applied by control coils



- We use a helical magnetic perturbation that reverses sign midway through the pulse (a “phase-flip”)
- Allows easier detection of the plasma response over a slowly evolving equilibrium

Plasma response to a resonant phase-flip perturbation is easily detected




- When the applied magnetic perturbation is resonant, the plasma strongly amplifies this perturbation. This is called resonant field amplification (RFA)
- The plasma's paramagnetic response is clearly seen in the first half of the perturbation, followed by a change in the sign of the response when the fields are flipped

Varying the applied field spectrum demonstrates resonant amplification




- The external field spectrum is continuously varied, with coil current in the i, j^{th} coil equal to:

$$Ic_{ij} = A \cos(m\theta_i + \varphi_j)$$




- The plasma response is proportional to the amplitude of the resonant 3/1 component in the applied perturbation, even though the total field is constant.
- When the applied field is non-resonant, the plasma simply ignores the field!

Plasma response increases dramatically as edge rotation is varied with edge biasing





- A biased probe is inserted in the plasma to induce ExB flow and change the plasma rotation
- The natural edge plasma rotation of 4-8kHz can be slowed to near zero rotation with about 40A of bias current
- At low rotation, plasma response is increased by a factor of three!

Plasma helicity scan demonstrates resonance




- Plasma response measured as a function of the equilibrium field helicity (edge q) shows a resonance near $q=3$
- In HBT-EP, edge q is essentially a measure of stability

Three regimes of plasma response observed as phase-flip amplitude is varied




- Three regimes of plasma response are observed:
 - I. Linear regime
 - II. Saturated regime
 - III. Disruptive regime (>30A)
- Plasmas always disrupt for large perturbations
- The saturated regime is only observed near resonance ($q \sim 3$)
- The slope of the linear response is higher near $q \sim 3$ (see q scan results)

Detailed q scan at two amplitudes confirm saturated response near resonance



- Away from resonance ($q < 2.85$), doubling the perturbation doubles the response, i.e. linear response
- Near resonance ($q \sim 3$), the response remains the same, i.e. saturation

Detailed q scan at two amplitudes confirm saturated response near resonance



- Away from resonance ($q < 2.85$), doubling the perturbation doubles the response, i.e. linear response
- Near resonance ($q \sim 3$), the response remains the same, i.e. saturation

-
- Introduction and Motivation
 - What do we mean by 3D magnetic fields, and why are they important?
 - The HBT-EP Device
 - Detection of natural plasma modes
 - Active driving of plasma with external fields, and detection of the plasma response
 - Summary

Summary



- 3D effects are important in expanding tokamak performance to the levels required for a fusion reactor
- HBT-EP is designed to clearly detect these effects, with unprecedented detail
- Passive measurements of natural rotating modes shows a rich spectrum of multiple independent modes
 - This implies the need for “multimode control” in future fusion reactors
- Probing the plasma with magnetic perturbations results in a large resonant field amplification (RFA)
 - RFA measured as a function of various plasma parameters provides information about the plasma and its stability properties